

SW NO	FUNCTION	POSITION
SW1	REC/P.B	P.B — REC
SW2	INPUT SELECT	LINE — MIC
SW3	DOLBY NR	OFF — ON
SW4	DOLBY B/C	B — C
SW5	TAPE SELECT	NORMAL — CrO2
SW6	TAPE SELECT	OTHER — METAL
SW7	POWER	OFF — ON
SW8	MUTING	OFF — ON
SW9	BIAS	OFF — ON
SW11	DIRECTION	FORWARD — REVERSE

- Specifications or wiring diagrams of this model are subject to change for the improvement without prior notice.

MODEL RT-320H